



AWSA Protocol E4

Standard Operating Procedure – Management of Contaminated Water

The following procedures will be adhered to for any rinsate generated as part of container cleaning or flushing of the treatment system:

1. Seed treatment containers are returned unrinsed to the vendor/supplier. No Rinsate is produced on location as a result.
2. All seed treating equipment will be cleaned using air to flush lines, all treatment will be returned to original container for future use. A dry wipe/clean will be done on all other components.